

Using COMPOSER™ to Create Custom Gas Mix Compositions

To remain accurate, your flow controller needs to know the viscosity of the gas you are flowing through it. The more closely you can define your actual gas composition, the more accurate your flow readings will be. Alicat's COMPOSER™ is an included feature of Gas Select™ that lets you define new mixed gas compositions to reconfigure your flow controller on the fly.


COMPOSER™ uses the Wilke method to define a new gas mixture based on the molar (volumetric) ratios of the gases in the mixture. You can define these gas compositions to 0.01% for each of up to five constituent gases in the mixture. Once you define and save a new COMPOSER™ gas mix, it becomes part of the Gas Select™ system and is accessible under the gas category COMPOSER™ User Mixes. You can store 20 COMPOSER™ gas mixes on your flow controller.



Note: COMPOSER™ does not physically mix any gases, it configures your flow controller to report flow readings accurately based on the constituent gases of your mixture. If you require turnkey gas mixing, please contact Alicat.

Menu → Basic Config → Gas → **COMPOSER User Mixes**

To access COMPOSER™, select **COMPOSER User Mixes** from the Gas Select™ category listing. Select any existing mix to reconfigure your flow controller to flow that gas mixture. Select **Delete Mix** to permanently remove a gas mix.



SELECT Enters the COMPOSER™ Menu.


To access COMPOSER™, select **COMPOSER™ User Mixes** from the Gas Select™ category listing. Select any existing mix to reconfigure your flow controller to flow that gas mixture. Select **Delete Mix** to permanently remove a gas mix.

Add Mix Creates a new COMPOSER™ gas mix.

COMPOSER™ Mixes Selects an existing gas mix to use.

Delete Mix Deletes an existing gas mix. (Option appears if at least 1 mix exists.)

CANCEL Returns to the Gas Select™ Menu (page 34).



SET Confirms your selection and exits to the Main Display (page 17).



Note: Your Alicat device does not store the composition of saved gas mixes, only the required viscosity and density as a function of temperature and pressure. It might be helpful to write it down.


Adding a new COMPOSER™ mixed gas composition

Generate and store a new COMPOSER™ mix in 3 easy steps.



Note: You cannot save your mix until the total is 100%.

Saved gas compositions can be deleted, but not modified.



Gas List

#	Short Name	Long Name
0	Air	Air (Clean Dry)
1	Ar	Argon
2	CH ₄	Methane
3	CO	Carbon Monoxide
4	CO ₂	Carbon Dioxide
5	C ₂ H ₆	Ethane
6	H ₂	Hydrogen
7	He	Helium
8	N ₂	Nitrogen
9	N ₂ O	Nitrous Oxide
10	Ne	Neon
11	O ₂	Oxygen
12	C ₃ H ₈	Propane
13	nC ₄ H ₁₀	Normal Butane
14	C ₂ H ₂	Acetylene
15	C ₂ H ₄	Ethylene (Ethene)
16	iC ₄ H ₁₀	Isobutane ²
17	Kr	Krypton
18	Xe	Xenon
19	SF ₆	Sulfur Hexafluoride ¹
20	C-25	25% CO ₂ , 75% Ar
21	C-10	10% CO ₂ , 90% Ar
22	C-8	8% CO ₂ , 92% Ar
23	C-2	2% CO ₂ , 98% Ar
24	C-75	75% CO ₂ , 25% Ar
25	He-25	25% He, 75% Ar
26	He-75	75% He, 25% Ar
27	A1025	90% He, 7.5% Ar, 2.5% CO ₂
28	Star29	Stargon CS (90% Ar, 8% CO ₂ , 2% O ₂)
29	P-5	5% CH ₄ , 95% Ar
30	NO	Nitric Oxide ²
31	NF ₃	Nitrogen Trifluoride ²
32	NH ₃	Ammonia ²
33	Cl ₂	Chlorine ^{2,4}
34	H ₂ S	Hydrogen Sulfide ²

#	Short Name	Long Name
35	SO ₂	Sulfur Dioxide ^{2,4}
36	C ₃ H ₆	Propylene ²
80	1Buten	1-Butylene ²
81	cButen	Cis-Butene (cis-2-Butene) ²
82	iButen	Isobutylene
83	tButen	Trans-2-Butene ²
84	COS	Carbonyl Sulfide ²
85	DME	Dimethylether (C ₂ H ₆ O) ²
86	SiH ₄	Silane ²
100	R-11	Trichlorofluoromethane (CCl ₃ F) ^{2,3}
101	R-115	Chloropentafluoroethane (C ₂ ClF ₅) ^{2,3}
102	R-116	Hexafluoroethane (C ₂ F ₆) ²
103	R-124	Chlorotetrafluoroethane (C ₂ HCIF ₄) ^{2,3}
104	R-125	Pentafluoroethane (CF ₃ CHF ₂) ^{2,3}
105	R-134A	Tetrafluoroethane (CH ₂ FCF ₃) ^{2,3}
106	R-14	Tetrafluoromethane (CF ₄) ²
107	R-142b	Chlorodifluoroethane (CH ₃ CCIF ₂) ^{2,3}
108	R-143a	Trifluoroethane (C ₂ H ₃ F ₃) ^{2,3}
109	R-152a	Difluoroethane (C ₂ H ₄ F ₂) ²
110	R-22	Difluoromonochloromethane (CHClF ₂) ^{2,3}
111	R-23	Trifluoromethane (CHF ₃) ^{2,3}
112	R-32	Difluoromethane (CH ₂ F ₂) ^{2,3}
113	R-318	Octafluorocyclobutane (C ₄ F ₈) ²
114	R-404A	44% R-125, 4% R-134A, 52% R-143A ^{2,3}
115	R-407C	23% R-32, 25% R-125, 52% R-143A ^{2,3}
116	R-410A	50% R-32, 50% R-125 ^{2,3}
117	R-507A	50% R-125, 50% R-143A ^{2,3}
140	C-15	15% CO ₂ , 85% Ar
141	C-20	20% CO ₂ , 80% Ar
142	C-50	50% CO ₂ , 50% Ar
143	He-50	50% He, 50% Ar
144	He-90	90% He, 10% Ar
145	Bio5M	5% CH ₄ , 95% CO ₂
146	Bio10M	10% CH ₄ , 90% CO ₂
147	Bio15M	15% CH ₄ , 85% CO ₂